



Bottom of Fan Discharge Opening



ATTACHING A CONDENSATE PUMP TO THE **SANTA FE DEHUMIDIFIER**

 **Therma-Stor**
PO Box 8050, Madison, WI 53708
1-800-533-7533
www.thermastor.com



Drain Hose &
Grommet
See Note 3

 Existing Hole

Drill 1/8" Hole at "X"
Use Screw Provided
See Note 2



Drill 1/8" Hole at "X"
Use Screw Provided
See Note 2



Notes:

1. This sheet is a full size template for the pump mounting location below the fan discharge opening.
2. **CAUTION!** Drilling holes in the cabinet other than where specified may cause leaks in the refrigeration system. (newer models have holes at "x" locations and do not require drilling).
3. Cut Off The Original Drain Hose so the end of the hose goes into the outer hole on the condensate pump. Do Not push any of the original drain hose into the cabinet.



